

- Open the trailer and use stands to hold it open. Secure this stands. Check the saftey of the stands.
- Make sure that the top is full opened by shaking on the lift arms. You can hear the eyes of the gasstruts shaking on the bolt.
- Remove the carpet of the top attachment. Remove the small guide on the lower attachment by using a philips screwdriver.
- Remove the carpet on the telescope around the nut.
- Bottom: Open the security bolt with a philips screwdriver. Open the nut by using a pinspanner (or a pin and a hammer, or a pair of pliers).
- Open the top bolt with two 13 mm spanners. Remove the telescope arm. It is easy when the stands are in the right position to hold the trailers top in the right height. By difficultis move the stands until you reach the correct height.

Assemble the new struts in the opposite way as described above.

X tell this Numbers (Inside on the right hand triangular Aluminum plate) by ordering Gas springs

Your COBRA . Team